

Emergency Assembly Points

Sub Station 

Light Tower 

Vessel Working Exclusion Zone / Security Escort Only 

Stevedore Traffic Flow

- Berth 1 
- Berth 2 
- Berth 3 

Stop Sign 

Give Way Sign 

Traffic flow can change on a daily basis based on operational requirements.